

Figure 1




Figure 2

3/9




Figure 3




Figure 4a




Figure 4b




Figure 5




Figure 6




Figure 7




Figure 8




Figure 9a

Figure 9b

Asynchronous Client Trap Message <u>220</u>		Asynchronous Master Trap Message <u>194</u>	
Version Number <u>174</u>		Version Number <u>174</u>	
Protocol Data Unit <u>184</u>	Enterprise Agent Address Generic Trap ID Specific Trap ID Time Stamp <u>187</u>	Protocol Data Unit <u>178</u>	Enterprise Agent Address Generic Trap ID Specific Trap ID Time Stamp <u>180</u>
COID <u>188</u>	Value <u>176</u>	MOID <u>182</u>	Value <u>176</u>

Figure 10

Trap Rules <u>38</u>		
Trap ID	COID <u>188</u>	Rule
		Convert to Master MIB Variable and Send to SNMP Manager
		Ignore

Figure 11